33 Green Lane, Lofthouse, Wakefield,
West Yorkshire, WF3 3QJ
Tel: 01924 871246 Fax: 01924 871866
Email: sales@foreverpromotions.com
Web: www.foreverpromotions.com

Forever Jigsaw

User Instructions

Data Sheet

Packaging: Forever Vairofilm

Sheets:

A3 (420mm X 297mm) A4 (297mm X 210mm)

Printer Settings

* Mirror Image
* Normal paper stock should be selected

Transfer-Press Settings

	Automatic Press	Manual Press
Pressure	High 5 - 6 PSI	High
Temperature	180 °C	180 °C
Time	35 Seconds	35 Seconds

Transfer Process

1) Remove the silicone backing sheet.
2) Place image onto substrate sticky side facing up.
3) Cover the substrate with a sheet of silicone.
4) Cover with the rubber heat mat.
5) Press for 35 seconds.
6) The jigsaw should be allowed to cool completely before removing the film.

Tip

* If white lines appear on jigsaw when removing the film then substrate hasn't been allowed to cool long enough.

Copyright ©2006 ForeverPromotions.com

Forever Promotions uk

Digitally signed by Forever Promotions uk
DN: CN = Forever Promotions uk, C = GB, O = ForeverPromotions, OU = Web Developer
Reason: I am the author of this document
Date: 2006.09.13 00:32:08 +01'00'