

## Forever Rubber Coasters User Instructions

### Data Sheet

**Packaging:**

**Forever Classic**

**Sheets:**




A3 (420mm X 297mm)

A4 (297mm X 210mm)

### Printer Settings

- \* **Mirror Image**
- \* **Normal paper stock should be selected**

### Transfer-Press Settings

	<u>Automatic Press</u>	<u>Manual Press</u>
 <b>Pressure</b>	<b>High 5 - 6 PSI</b>	<b>Medium - High</b>
 <b>Temperature</b>	<b>180 °C</b>	<b>180 °C</b>
 <b>Time</b>	<b>10 Seconds</b>	<b>10 Seconds</b>

### Transfer Process

- 1) **Pre - press the garment to remove any moisture.**
- 2) **Cut the mirrored image as required.**
- 3) **Put the image, face down, onto the garment.**
- 4) **Press for 13 seconds.**
- 5) **Hot peel.**
- 6) **Pull garment sideways to loosen the image.**

### Washing Instructions

- \* **Wash inside out up-to 60 °C**
- \* **Iron over image – to regenerate toner**
- \* **Do Not Dry clean or Tumble dry.**
- \* **Use standard washing powders Do Not use bleach or softener.**